



NORMAL CHECKLIST B738/B38M

NOV 2025

B737 MAX / NG	NC	
PRE FLIGHT		
CVRChecked	F/O	
OXYGENTested, 100%	C, F/O	
NAVIGATION Transfer and DISPLAY switchesNORMAL, AUTO	F/O	
Window HeatON	F/O	
Pressurization Mode SelectorAUTO	F/O	
Flight InstrumentsHeading,Altimeter	C, F/O	
Parking BrakeSET	С	
Engine Start LeversCUT OFF	С	
BEFORE START		
Flight Deck DoorClosed and Locked	F/O	
FuelKGS, Pumps ON	F/O	
Passenger SignsON	F/O	
WindowsLocked	C, F/O	
MCPV2,HEADING,ALTITUDE	С	
Takeoff SpeedsV1,VR,V2	C, F/O	
CDU PreflightCompleted	C, F/O	
Rudder and Aileron TrimFree and 0	C, F/O	
Taxi and Takeoff BriefingCompleted	PF	
Anti Collision LightON	F/O	
BEFORE TAXI		
GeneratorsON	F/O	
Probe HeatON	F/O	
Anti-ice	F/O	
Pack SwitchesAUTO	F/O	
Isolation ValveAUTO	F/O	
APU	F/O	
Engine Start SwitchesCONT	F/O	
RecallChecked	C, F/O	
Auto BrakeRTO	F/O	
Engine Start LeversIDLE Detent	С	
Flight ControlsChecked	С	
Speed BrakesDown Detent	С	
Flaps, Green Light	C, F/O	
Ground EquipmentClear	C, F/O	
BEFORE TAKEOFF		
Flaps, Green Light	PF	
Stabilizer TrimUnits	PF	

B737 MAX / NG	NC	
AFTER TAKEOFF		
Engine BleedsON	РМ	
PACKSAUTO	РМ	
Landing GearUP [MAX] / UP and OFF [NG]	РМ	
FlapsUP, No Lights	РМ	
DESCENT		
Flight Deck DoorClosed and Locked	РМ	
PressurizationLAND ALT	PF, PM	
RecallChecked	РМ	
Landing DataVREF,Minimums	PF, PM	
Approach BriefingCompleted	PF	
APPROACH		
Altimeters	PF, PM	
LANDING		
Engine Start SwitchesCONT	РМ	
Speed BrakesARMED	PF, PM	
Landing GearDown	PF, PM	
Flaps, Green Light	PF, PM	
SHUTDOWN		
Fuel PumpsOFF	F/O	
Probe HeatAUTO	F/O	
Hydraulic PanelSet	F/O	
FlapsUp	F/O	
Parking Brake	С	
Engine Start LeversCUT OFF	С	
Weather RadarOFF	F/O	
SECURE		
IRSsON	F/O	
Emergency Exit LightsOFF	F/O	
Window HeatOFF	F/O	
PacksOFF	F/O	